



## CABINPUMP

### WASTEWATER SYSTEM

Pump Temporary Accommodation Wastewater Directly to a Mains Sewer or to Larger Storage Tanks

- Minimise or eliminate waste tanker visits on your sites
- Plug & Play - No commissioning required
- Portable, Powerful & Tough



1. Connect the incoming waste pipe to pre-installed 4" / 100mm connection point



2. Connect the pumping main to the supplied compression fitting



3. Plug in to 240V power supply from the cabins and turn on!

CABINPUMP Model	1.5	1.5+
Number of WC's	20	20
Number of People	150	150
Dimensions (LxWxH) (mm)	1000x900x600	1000x900x600
Max Pumping Distance	605 m	605 m
Max Pumping Height	15.3 m	15.3 m
SMS/Email Alert System	No	Yes
Fork/Strap Lifting Pockets	No	Yes
Pumping Main Required (OD)*	63 mm	63 mm

Pump Type	Macerator
Power Supply	230 V
Power Rating	1.1 kW
Rated Current	4.97 A
Starting Current	24.85 A
Thermal Pump Protection	Included
Power Connection	32A Commando Plug

\*Rising main preferred specification SDR17 Black